

1956 Chevrolet Installation Instructions

1. **Disconnect Battery.** Do not skip this step. Also, do not try to “test” the LED array by connecting the leads directly to your battery. Permanent damage will occur to the LED array if you fail to heed these steps.
2. Remove Taillight Lens.
3. Remove light bulb.
4. Remove the boot on the back of the taillight.
5. Disconnect the harness from the taillight by turning the plastic connector clockwise.
6. Choose a location to splice to the old harness. This can be in the quarter panel or in the trunk. The trunk is preferred, but the supplied connectors are waterproof so connection in the quarter panel will not cause any problems. Cut the old harness at your chosen location. The taillight harness consists of black and pink wires on the driver’s side or black and purple wires on the passenger side.
7. Pass the supplied LED harness through the through the hole where the bulb was removed to the desired location. The plastic LED connector should be about three inches beyond the taillight.
8. **Driver’s side.** Using the supplied connectors, connect the black wire on your car to the black wire on the supplied harness. To use the connector: put both wires in a separate hole, unstripped. Holding the wires as far in as possible, squeeze the connector with pliers. Some “goo” may come out of the connector. This “goo” ensures a watertight connection. Repeat by connecting the pink wire on your car to the red wire on the supplied harness. If your car does not have an original wiring harness, the black wire goes to the taillight circuit and the red wire goes to the stop light circuit.
9. **Passenger side.** Using the supplied connectors, connect the black wire on your car to the black wire on the supplied harness. To use the connector: put both wires in a separate hole, unstripped. Holding the wires as far in as possible, squeeze the connector with pliers. Some “goo” may come out of the connector. This “goo” ensures a watertight connection. . Repeat by connecting the purple wire on your car to the red wire on the supplied harness. If your car does not have an original wiring harness, the black wire goes to the taillight circuit and the red wire goes to the stop light circuit.

10. Attach the plastic connector on the supplied harness to the LED arrays.
11. Attach the green wire on the supplied harness to one of the two lens screws or one of the screws on the LED array. The ground ring terminal should go underneath the lens gasket if attached to a lens screw.
12. Install the LED arrays on both sides of the car. Remove the nut and plastic wire guide from the back of the LED arrays. Pass the wiring harness and the 2-inch long screw through the hole where the bulb was removed. Pass the harness through the plastic wire guide (see photo). Install the wire guide and nut. Note the orientation of the LED array in the photo. Do not over tighten. The LED bracket will bend easily.
13. Position the lens gasket and reinstall the lens. Do not over tighten the lens screws!
14. Repeat for the other side.
15. Reconnect the battery.
16. Test both STOP and taillight functions.
17. Enjoy!



Shiny-Hiney.com
513-607-5617
email: sales@shiny-hiney.com